

A-Core Container

Light Wind Portable Power Supply

DETAILS AND PACKAGING



1 USER MANUAL PDF

2 RJ45 Cable For RS485/CAN

3 Battery in Parallel Cables

4 RJ45 TO USB Monitor Cable

5 M8 Terminal*4

Light Wind Portable Power Supply

Contact Us

For catalog requests, pricing, or partnerships, please visit:
<https://a-core.pl>