

A-Core Container

Energy storage liquid cooling host and compressor



Overview

The liquid-cooled host uses compressor power to open the refrigerant circulation loop. The refrigerant is throttled and decompressed through the electronic expansion valve, and enters the liquid-cooling plate to contact the battery core for heat exchange, thereby achieving battery pack cooling.

Energy storage liquid cooling host and compressor

Contact Us

For catalog requests, pricing, or partnerships, please visit:
<https://a-core.pl>